








197-000172



Instruction Manual





A01 20x *14 mm	A02 20x *5x45 mm	A03 20x *8x30 mm	A04 20x
A10 51x *4x20 mm	A13 6x 	A14 2x 	A15 8x
A16 4x 	A17 1x 	A18 3x 	





Important information
Read carefully.
Keep this information for further reference.

GB WARNING



Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.




8.





9.






10.




1.




2.




3.





4.



5.



6.



7.

