




















197-000174




Instruction Manual






A01 24x  *14 mm	A02 24x  *5x45 mm	A03 24x  *8x30 mm	A04 24x 
A09 30x  *4x25 mm	A10 32x  *4x20 mm	A11 4x 	A13 4x 
A14 4x 	A28 12x 	A46 5x 	A60 2x 


5.







1.



2.



3.



4.

