












Assembly Instruction

278-000012



| | | | |
|---|---|---|---|
|  |  |  |  |
| Ax1 | Bx1 | Cx1 | Dx1 |
|  |  |  |  |
| Ex1 | Fx4 | Gx1 | Hx1 |