

















HARDWARE ITEM		QTY
A2	 Screw m3.5 x 14mm	44
A4	 Screw m3.5 x 20mm	4
A6	 Screw m4 x 25mm	4
A17	 Crosshead Screw m6.3 x 40mm	24
A18	 Crosshead Screw m6.3 x 50mm	4
C5	 Square Lock Set	1 Set
E9	 Door Hinge 7/8"	4
H3	 Handle 96mm (Silver)	2
L2	 Plastic Leg L Shape	4
N1	 Allen Key	1
N3	 Nail	50 (+-3)
R1	 L Bracket	2
S1	 Door Catches	1
S2	 Door Stopper	1

COMPLETE




PRE - ASSEMBLY

STEP 1 Assemble the Door Catches (S1) at panel no. 3 by using Screw m3.5 x 14mm (A2). Assemble the Door Hinges 7/8" (E9) by using Screw m3.5 x 14mm (A2) and assemble the Handle (H3) by using Screw m4 x 25mm (A6) at panel no. 3 & 4. Then, assemble the Square Lock Set (C5) at panel no. 4 by using Screw m3.5 x 20mm (A4).



STEP 2 Insert the Door Stopper (S2) at panel no. 6.




CAUTION

MATERIAL USE LAMINATED PARTICLE BOARD, TO CLEAN USE SOFT, DRY CLOTH. DO NOT USE DETERGENT OR CHEMICAL AVOID CONTACT WITH WATER AND DIRECT SUNLIGHT. TO BE ASSEMBLED ON A SOFT, DRY, CLEAN SMOOTH SURFACE.


USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.




STEP 3 Assemble panel no. 2, 5, 6, 7 & 8 together by using Crosshead Screw m6.3 x 40mm (A17). Use Allen Key (N1) to tighten the Crosshead Screw m6.3 x 40mm (A17).




STEP 4 Assemble panel no. 1 to the unit by using Crosshead Screw m6.3 x 40mm (A17). Use Allen Key (N1) to tighten the Crosshead Screw m6.3 x 40mm (A17).



STEP 5 Assemble panel no. 9 to the unit by using Crosshead Screw m6.3 x 50mm (A18). Use Allen Key (N1) to tighten the Crosshead Screw m6.3 x 50mm (A18).



STEP 6 Assemble the panel no. 10 to the unit by using Nail (N3). Then, assemble the L Bracket (R1) at between panel no. 5 & 8 by using Screw m3.5 x 14mm (A2). Assemble the Plastic Leg L Shape (L2) between panel no. 8 & side panels by using Screw m3.5 x 14mm (A2).



STEP 7 Attach the door panels no. 3 & 4 to the unit. Adjust the Door Hinges 7/8" (E9) to screw parallel between the door gaps.

